

eCode Reader

Introduction

Todos eCode™ Reader, together with a smart card, is a small, portable, virus free and cost efficient solution for secure remote authentication. For demo purpose the following functions are available:


- CODE: One Time Password for identification
- EPURSE: for reading balance and transactions of an electronic purse.

Todos online eCode demo bank is located at: www.ecode.se

There you can try your Todos eCode™ Reader together with your Todos eCode™ demo card.

Important Notes!

- Do not keep card in the eCode Reader when not in use. (battery may drain)
- Do not generate One Time Passwords if you do not intend to use them for login since you may get out of sync and then locked out. The bank/service provider decides how many attempts you get. In the demo version you have 3 attempts before you get out of sync and have to resync. If you generate another 30 codes without using them you will be permanently locked out.



EPURSE



When you insert your Proton ePurse card in the Todos eCode™ Reader, the balance is shown in the display.



To scroll through your latest transactions, press the lower button.



You can return to the balance by pressing the upper button.

CODE



When you insert your Todos eCode™ demo card in the Todos eCode™ Reader a unique One Time Password is presented in the display.

You use this code to login to your Internet Bank account or use it for Telephone banking. It is advised to use a static password in combination with this OTP for higher security.